
# CONSTRUCTION specs & options

# SPRAY FOAM INSULATION RIGS

Not all rigs are equal. What to know before you buy.




## CONSIDER TRAILER STYLE






## **CONSIDER DOOR TYPE**




Barn Doors

Ramp Doors

## TRAILER FRAMEWORK





sensitive chemicals like isocyantaes. Choose a high temperature refrigerated air

Air Dryer

to assure proper function

temp rated for 180° F.

Compressor

Select an air compressor to

neet all your air requirement

requiring compressed air: spray gun,

power tools, etc. Consider the pros and

cons of the compressor power source:

electrical, gas, alternator take-off

when making a buying decision. Be

sure to only use a "continuous run"

style compressor.

The generator exhaust should be installed

using a flexible exhaust element, and be

sure exhaust hole is properly sealed.



Be sure the radiator on your generator is properly vented to the outside and

fresh air is available using an

engineered louver system.

Diesel generators provide consistent, clean electricity to properly power your equipment for years of trouble free service. Consider all items that will require power: proportioner,

heated hoses, refrigerated air dryer, air compressor,

power tools, lights, auxiliary outlets, heat/AC units,

when sizing your generator. Be sure to consider the

effect on tongue weight when determining the

Generator

location of the generator.

Consider your typical spray environment. HVAC may be interior of your rig to maintain your chemicals at an appropriate temperature.

separating your generato

room for your generator will help you

## Agitator Some materials require mixing to optimize yield and performance. Follow your chemical manufactures

recommendations to determine if an agitator is required. Options include expanding blades or twistork style.

5/16 in. plywood walls for interior covering on walls and ceilings. Walls and ceiling should be protected from damage from spills and abuse.


A minimum of

### The primary piece of equipment required to spray foam insulatioin is your sprayer. Popular sprayers come in three types: electric, hydraulic, and air sprayers. The sprayers' job is to heat and pressurize the A and B chemicals and deliver them to the gun. Consider your typical applications, desired

Sprayer

and remote reporting needs when selecting a sprayer.

outputs, hose lengths, data capture



Insulated ceilings, walls and floor to maintain a constant temperature is important when working with chemicals that are temperature sensitive.

## Heated Hose

Hoses are engineered to precisely heat and work seamlessly with proportioners allowing for fast and uniform heating. Consider temperature monitoring technology of your proportioner, safety ratings of the hose, spray pressures, and scuff guard materials when selecting a heated hose.

Floor covering should be robust and stand up to years of day to day abuse including chemical spills and the daily loading of drums and equipment. Typical coverings include polyurea or diamond plate.

Hose rack with a minimum 15 in. diameter

should be used to hold your hoses without

creating pinch points or kinks on your

## Transfer Pump

Transfer pumps are required to feed chemical to your proportioner. Consider material viscosities, desired output rate, interior ceiling height of your rig, available air pressure when choosing a transfer pump. Make sure to use a desiccant dryer on the "A-side" drum.

Consider a work bench/tool box to store tools and supplies and a clean place to make equipment repairs. Keep a spare gun and repair parts on hand to minimize unforeseen downtime.

## Spray Gun


allows your hose

to run outside and allow

ig shut for better interior

vou to keep the doors of the

A two-component spray gun is where the spray foam chemicals are mixed. Most down time is related to the spray gun, so choose wisely. Guns come in a variety of technology including air, mechanical and liquid purge. Choosing a gun that's right for you comes down to desired output, materials being sprayed, applications and personal preference.




necessities



Fire Extinguishers Minimum two 5 lbs, ABC approved

OSHA requires you to have SDS for all chemicals in your rig. Keep a binder to make it easy!

**Emergency Eye Wash** Minimum 15 gallon









Designed to safely hold and transport 55 gallon drums

of full chemical. Welded metal racks with arched drum nests and ratcheting straps are a common robust design. Consider how many sets of material you will be typically carrying and size your bracing appropriately.



## Breathable Air

Options include low pressure systems and supplied air 4-stage systems. Consider the application and environment when making a decision. Assure installation is done according to manufactures' instructions using all the proper plumbing and hardware.

